

Country of Origin: U.S.A.  
Procedencia: E.U.A.

Importado por:  
Importadora Primex S.A. de C.V.  
Blvd. Magnocentro No. 4  
San Fernando La Herradura  
Huixquilucan, Estado de México  
C.P. 52765  
RFC: IPR-930907-S70  
(55)-5246-5500  
www.costco.com.mx



# KAYAK OWNER'S MANUAL

Item No. 1273161

Model 90915

*Please read the instructions before using this product.*

## Transportation

Use caution when transporting your kayak. Be sure to tie down your kayak, but do not overtighten the straps.

## Storage

- Be sure to empty the kayak of all water.
- You should clean the kayak by rinsing with freshwater, especially if the kayak has been used in salt water or becomes muddy.
- Store the kayak out of direct sunlight.

## Usage

Sit in the cockpit area of the kayak, centered in the provided seat area. Using the foot braces, secure your feet so your knees are bent and feel sturdy. Paddle with your arms evenly apart at a medium speed switching back and forth from one side to the other. The paddle should enter the water around your shins and pull out of the water around your hips.

## WARNING

**Paddle sports can be physically demanding and dangerous.**

- Anyone using this watercraft may be at risk of serious injury or death.
- Obtain certified watercraft and first aid training, and carry first aid and safety/rescue equipment.
- Consult a physician prior to beginning your paddle sport training.
- This watercraft is intended for recreational use only.
- This watercraft is not intended for mechanical propulsion.
- Scout unfamiliar waters; portage where appropriate.
- Never use this watercraft in rough, stormy, or white water conditions.
- This watercraft is not intended to be used as a lifesaving device.
- Always wear a Coast Guard approved personal flotation vest.
- Do not allow minors to use this watercraft without adult supervision.
- Do not use in areas where dangerous or strong current flows can overcome your ability to control your direction or destination.
- Never use drugs or alcohol before or during operation of this watercraft.
- Always paddle with a buddy in case you require emergency help.
- Never use in cold water that may cause hypothermia.
- Always wear a helmet when appropriate.
- Check your equipment prior to each use for signs of wear or failure.

Keep this Identification Number in case you must contact our Customer Service Department.

## CLEANING & CARE

Congratulations on your Emotion® kayak purchase. By following the instructions below, your new Emotion® kayak should provide you with years of service and enjoyment.

### Cleaning and Care

Emotion® kayaks are stain- and solvent-resistant. Most stains can be removed using a mild soap and a soft-bristled brush. Abrasive cleaning materials may scratch the plastic and are not recommended. Avoid placing a direct heat source on or near surfaces unless using a heat barrier.

### Helpful Tips For Your Watercraft

- Always store your kayak out of direct sunlight when not in use. Your kayak is manufactured with UV-resistant color, but a kayak stored in direct sunlight will begin to color fade over long periods of time.
- Your new kayak is molded of high-density polyethylene resin. Periodically cleaning with mild soap and water is recommended to keep your kayak looking new.
- Never drag any portion of the kayak over asphalt, rocky, sandy or abrasive surfaces.
- Do not stand or sit on your kayak when out of the water. This can cause damage to the hull.
- During regular use, it is normal to find small amounts of water inside the kayak. Carefully unscrew the drain plug and tilt the kayak to let the water drain out. Secure the drain plug when finished.
- If your kayak has been exposed to hot sunlight, it is recommended to splash water on the hull to cool the hot surface before it comes in direct contact with your skin. This should also be done for any paddles you may have.

### **\*\*U.S. and Canada customers ONLY\*\***

IF ASSISTANCE IS NEEDED,

**DO NOT CONTACT THE STORE!**

**CALL OUR CUSTOMER SERVICE DEPARTMENT at 1 (800) 225-3865**

HOURS: 7:00 a.m. to 5:00 p.m. Monday through Friday (Mountain Standard Time)

\*\*Call, or visit our Web site for Saturday hours\*\*

\*\*For customers outside the U.S. or Canada, please contact the store for assistance.\*\*

Please have the Product ID ready when you call; it is located at the bottom of the first page of this instruction.

**Please save this instruction in the event you need to contact the manufacturer.**

Country of Origin: U.S.A.  
Procedencia: E.U.A.

Importado por:  
Importadora Primex S.A. de C.V.  
Blvd. Magnocentro No. 4  
San Fernando La Herradura  
Huixquilucan, Estado de México  
C.P. 52765  
RFC: IPR-930907-S70  
(55)-5246-5500  
www.costco.com.mx



# MANUAL DEL USUARIO KAYAK

Artículo No. 1273161

Modelo 90915

*Lea las siguientes instrucciones antes de usar el producto.*

## Transporte

Tenga cuidado al transportar su kayak.  
Al atar un kayak en el techo de un vehículo o de un estante, tenga cuidado de no apretar demasiado las correas.

## Almacenamiento

- Asegúrese de vaciar del kayak toda el agua.
- Usted debe limpiar el kayak enjuagándolo con agua fresca, especialmente si el kayak ha sido usado en agua salada o tiene lodo.
- Guarde el kayak lejos de la luz solar directa.

## Uso

Siéntese en el área de la cabina del kayak, centrado en el área del asiento proporcionado. Usando los tirantes del pie, asegure sus pies para que sus rodillas estén dobladas y se sientan fuertes. Reme con sus brazos uniformemente separados a una velocidad media alternándolos desde un lado a otro con el remo entrando en el agua alrededor de espinillas y sacando del agua alrededor de sus caderas.

## ¡ADVERTENCIA!

**Deportes acuáticos pueden ser físicamente exigentes y peligrosos.**

- Todos que usan este vehículo acuático sufren riesgo de lesiones graves o muerte.
- Obtenga entrenamiento acreditado y conozca sus límites antes de usar este vehículo acuático.
- Este vehículo acuático está pensado sólo para el uso recreativo.
- Nunca use este vehículo acuático en aguas rápidas.
- Nunca use este vehículo acuático en condiciones tempestuosas.
- Este vehículo acuático no está diseñado para ser utilizado como dispositivo de flotación.
- Siempre lleve un chaleco salvavidas personal aprobado por la guardacostas.
- No permita a los menores usar este vehículo acuáticos sin supervisión adulta.
- No use este vehículo acuático en áreas donde aguas rápidas o corrientes peligrosas pueden superar su habilidad de controlar su dirección o destinación.
- Nunca consuma drogas o alcohol antes de o durante el manejo de este vehículo acuático.
- Siempre reme con un amigo en caso de una emergencia.
- Nunca use este vehículo acuático en agua fría que puede causar hipotermia.
- Siempre lleve un casco cuando sea apropiada.
- Verifique el equipo antes de cada uso para señales de deterioración o fallo mecánico.

Guarde este número de identificación, en caso que tenga que comunicarse con el Departamento de Servicio al Consumidor.

La identificación se encuentra en la página 1

## LIMPIEZA Y CUIDADO

Felicitaciones por su compra Emotion®. Si cumple todas las instrucciones siguientes, podrá disfrutar satisfactoriamente del servicio de su nuevo producto Emotion®.

### Limpieza y Cuidado

Los kayaks Emotion® son resistentes a las manchas y al solvente. Se pueden limpiar la mayoría de las manchas usando un jabón suave y un cepillo de cerdas blandas. Los materiales limpiadores abrasivos podrían raspar el plástico y no son recomendados. Evite colocar una fuente directa de calor sobre la superficie o cerca de ella a menos que use una barrera contra el calor.

### Consejos útiles para su kayak

- Almacenar siempre el kayak lejos de luz solar directa cuando no se utilice. El color de su kayak ha sido fabricado a ser resistente a las rayas ultravioletas, mas el color del kayak empezará a desteñir si está almacenado bajo luz solar directa durante periodos prolongados.
- Su nuevo kayak ha sido moldeado de resina polietilena de alta densidad. Recomendamos limpiarlo periódicamente con agua y un jabón suave para mantener el kayak como nuevo.
- Nunca arrastrar ni una parte del kayak sobre asfalto, o superficies rocosas, arenosas, o abrasivas.
- No pararse ni sentarse en el kayak cuando esté fuera del agua; esto puede dañar el casco.
- Durante uso regular, es normal encontrar pequeñas cantidades de agua en el kayak. Desenrosque cuidadosamente el tapón de drenaje e incline el kayak para drenar el agua. Atornille el tapón una vez que haya terminado.
- Si el kayak ha sido expuesto a luz directa del sol, se recomienda salpicar agua en el casco para refrescar la superficie antes que entre en contacto directo con la piel. Esto también se debe hacer para cualquier paletas que pueda tener.

## ¡NO CONTACTE LA TIENDA!

**LLAME A NUESTRO DEPARTAMENTO DE SERVICIOS A CLIENTES  
al 1.800.225.3865**

HORAS: 07:00–17:00 lunes a viernes (HNR); 09:00–13:00 sábado (HNR)

Favor de tener la identificación del producto disponible antes de llamar; está ubicado en la esquina inferior izquierdo de la primera página de este manual.

La Garantía del fabricante no es válida en México.

Si tiene preguntas o necesita asistencia al cliente, contáctese con el Importador, en territorio Mexicano.

**\*\*Clientes de los E.U.A. o de Canadá SOLAMENTE\*\***

PARA LOS CLIENTES AFUERA DE LOS ESTADOS UNIDOS O DE CANADÁ, PÓNGASE EN CONTACTO CON LA TIENDA.

**Guarde este manual del usuario para referencia futura y por caso que tenga que ponerse en contacto con el fabricante.**